

IMPORTANT NOTICE

PLEASE DO NOT RETURN TO STORE.
If you have any problems with this unit,
contact Consumer Relations for service
PHONE: 1-800-275-8273 or
visit our website at wppotsandpans.com
Please read operating instructions
before using this product.
Please keep original box and packing materials
in the event that service is required.

W.P. APPLIANCES, INC. Toll Free (800) 275-8273 Website:

Model WPMFP15AC Printed in China REV 1.0


All trademarks, service marks and trade names (collectively the "Marks") are proprietary
to Wolfgang Puck World Wide.

Wolfgang Puck

12 - Cup Food Processor
Continuous Flow
Attachment manual

For use with
Wolfgang Puck
12-cup Food Processor
Model WPMFP15





Care and Cleaning

Wash the processing bowl, food collector, and ejector disc in warm water using a mild detergent (or see dishwasher instructions below). Dry each part thoroughly before use.

Dishwasher Use


All plastic components deteriorate through the prolonged use of a dishwasher for cleaning. However all parts of your continuous flow attachment are tolerant to dishwasher use. If using the dishwasher, place parts only on the top rack.



Wolfgang Puck,

owner of the famous Spago restaurants and one of the most influential chef-restauranteurs in America, is credited with reviving California's rich culinary heritage. His cooking innovations, a result of blending fresh

California ingredients with his classical French techniques, are enjoyed by world leaders, stars and fellow chefs alike. He established other trend-setting restaurants like Postrio in San Francisco, Chinois on Main in Santa Monica, Vert and Trattoria del Lupo, and his latest creation, Cut, a gourmet steakhouse in the Beverly Wilshire Hotel. Home chefs can also share Mr. Puck's talents through his cookbooks and, of course, through his appliances!



Know Your Continuous Flow Attachment



Processing Bowl with Chute

Specially designed to encourage processed food to be guided into the food collector. Designed for minimal mess as this chute fits together with the food collector.



Food Collector

Uniquely designed to fit underneath processing bowl with chute for effortless, no mess food collection. Holds large quantities of food, ensuring continuous processing with no interruption.



Ejector Disc

This disc features specially designed ribs to direct food from the processing bowl to the food collector.

3

Fitting the Continuous Flow Attachment (Sold separately)

Before Using the Continuous Flow Attachment

Wash the processing bowl with chute, ejector disc and food collector in warm water using a mild detergent. Dry each part thoroughly before use. Before you assemble your Food Processor, ensure that the power cord is unplugged.



- 1 Place the motor base facing you on a dry, level surface.
- 2 Place the processing bowl onto the motor base, the bowl will only sit correctly on the base when the handle is positioned to the right.



- 3 Rotate the handle clockwise to lock as indicated by the graphics on the left side of the motorbase.



- 4 Fit the spindle onto the drive shaft.



- 5 Fit the ejector disc over the spindle.



- 6 Fit the required disc for processing above the ejector disc on the spindle.



- 7 Position the lid onto the processing bowl, ensuring that the lid locks into place, following lock directions on lid.

- 8 Fit the Food Collector underneath the processing bowl chute. The Food Collector should fit alongside the food processor and the opening of bowl should be in line with the chute. See figure 1 for the properly assembled unit.



figure 1

4

